

**Our Vision Is To Be Our Customers Preferred Container Supplier**



## **Steel Drum Closure & Assembly Instructions**

### **CLOSURE SYSTEM COMPONENTS**

UN certified container closures must be installed and secured in accordance with the following procedure and specifications **This Procedure is for new steel drums manufactured by North Coast Container only!**

To ensure compliance to UN markings, the filler/shipper must inspect and confirm all closures are properly installed and at proper torque prior to shipping.

**Do Not Mix Different Drum Manufacturers' Components!** For drums manufactured/ re-manufactured by other suppliers, consult your specific supplier closing requirements.

### **Open Head Drum Closure Procedure**



- 1** Inspect the gasket for proper seating and remove any residue from curl prior to cover installation.
- 2** Place cover on drum, making sure the cover gasket is seated against drum curl and gasket is securely recessed in the cover channel. The gasket may not protrude outside the cover or drum curl or be sagging inside the drum. If the drum has a poly liner, the curl area must be free of wrinkles.
- 3** Place the cover ring onto the drum. Make sure the bolt ring is oriented so lugs are positioned below the top surface of the drum. Ensure it is centered on drum curl. Verify cover and drum curl are pinched together and within the recess of the ring profile. You are required to pound the ring with a non-sparking mallet or use a head press to compress the gasket.
- 4** **For bolt ring**—insert bolt into ring right lug. Thread jam nut onto bolt, if needed, and then into threaded lug, and tighten the bolt to specification. Hammer around circumference of ring while torque is applied to further seat head onto drum. **(Step 4 continued on next page)**

## Our Vision Is To Be Our Customers Preferred Container Supplier

Continue hammering on ring circumference and torque the bolt until the torque does not loosen when further hammering on the ring circumference is performed. Tighten jam nut against unthreaded lug. Ring ends must not touch when proper torque is applied.

**For lever ring**—hammer around circumference until lever can lock in place.

**\*It is the filler's responsibility to verify the container has been properly closed prior to shipping filled drums**

### Bung Closure Procedures

- 1 Inspect all bungs to ensure gaskets are in place and not twisted or damaged
- 2 Insert all bungs and hand thread in a clockwise direction until hand tight. **Do not cross thread**
- 3 Utilizing a CALIBRATED TORQUE WRENCH to torque and confirm all bungs are at required minimum torque. **Do not over tighten**
- 4 Wipe clean any spillage or debris.
- 5 If required, apply applicable cap seals

**16 Gauge Ring: Torque: 15 to 20 ft-lbs- No Jam Nut**

**12 Gauge Forged Lug Ring: Torque: 60 to 70 ft-lbs**


**1 5/8" Standard Drum Bolt...Jam Nut Required**

#### Notes:

This document must be passed along with the container within your facility, or to whom the packaging is transferred, and ultimately to the personnel responsible for shipping and closure. It must be used as a training document to complete proper closure of your container.

In order for your drum to safely perform to its rated ability, these assembly instructions must be strictly adhered to. Any other method of assembly will immediately invalidate the UN certification.

Disassembly of a poly lined drum voids UN certification.



#### Manufacturer's Recommendations [ft-lbs]-(tolerance +/- 10%)

Bung Type	Round Bung				Hexagon Bung			
Bung Material	Steel		Poly		Steel		Poly/Nylon	
Gasket Type	Rubber	Poly	Rubber	Poly	Rubber	Poly	Rubber	Poly
2"	20 ft-lb	30 ft-lb	20 ft-lb	15-20 ft-lb	30 ft-lb	40 ft-lb	20 ft-lb	20 ft-lb
1-1/2"	n/a	n/a	n/a	n/a	30 ft-lb	40 ft-lb	n/a	n/a
3/4"	9 ft-lb	15 ft-lb	9 ft-lb	9 ft-lb	15 ft-lb	20 ft-lb	9 ft-lb	9 ft-lb